

MAXIFY				
GX1020	GX2020	GX3020	GX4020	GX5020
GX5520X	GX602x	GX702x	iB4020	iB4120
MB2020	MB2120	MB2320	MB2720	MB5020
MB5120	MB5320	MB5420		

PIXMA G				
G620	G320x	G326x	G3270	G4200
G4210	G5020	G6020	G7020	

PIXMA iP / iX				
iP110	iP7220	iP8720	iX6820	

PIXMA MG				
MG292x	MG302x	MG312x	MG322x	MG352x
MG3620	MG4120	MG4220	MG5220	MG5320
MG542x	MG552x	MG5620	MG572x	MG6120
MG6220	MG6320	MG6420	MG6620	MG682x
MG7120	MG7520	MG7720	MG8120	MG8220

PIXMA MP				
MP495	MP499	MP560	MP640	MP640R
MP990				

PIXMA MX				
MX340	MX350	MX410	MX420	MX43x
MX45x	MX47x	MX49x	MX512	MX522
MX532	MX712	MX722	MX870	MX882
MX892	MX922			

PIXMA TR				
TR15x	TR452x	TR472x	TR702x	TR7520
TR7820	TR8520	TR862x		

PIXMA TS				
TS302	TS70x	TS312x	TS332x	TS352x
TS372x	TS5020	TS5120	TS5320	TS6020
TS6120	TS6220	TS6320	TS642x	TS7720
TS8020	TS8120	TS822x	TS832x	TS9020
TS9120	TS952x			

SELPHY				
CP900	CP910	CP1200	CP1300	CP1500

PIXMA / imagePROGRAF PRO				
PRO-10	PRO-100	PRO-200	PRO-300	PRO-1000

imagePROGRAF TC				
TC-20	TC-20M			