

Install the Drivers & Software

If your PIXMA mg7120 has already been set up on your wireless network, it is only necessary to install the software and drivers to the computer(s) on your wireless network. It is not necessary to reset the printer or make additional settings.

To begin setup of your PIXMA mg7120 to additional computers on on your wireless network, insert the Setup CD-ROM* in your computer.



The setup program will start automatically.


*If you don't have or cannot use the Setup CD-ROM, follow the steps below to start the setup.

- [Download the software](#) (click the link to download)
- Double-click the downloaded .exe file (Win-mg7100-1_1-ucd.exe)

If the **User Account Control** dialog box appears during the setup, click **Yes** or **Continue**.

Install the Drivers & Software


Click **Next** on the initial screen



Install the Drivers & Software

Continue following on-screen instructions. On the **Software Installation List**, select *software to install and click **Next**.


***MP Drivers** is required and cannot be deselected. We recommend installing **My Image Garden** and **Quick Menu** to take full advantage of the printer's features.



Complete the Setup

Continue following on-screen instructions.

When the **Setup Completion** dialog box appears, click **Complete**.



At this point, setup of the printer and network is complete. Continue to follow any remaining on-screen instructions to finish and exit the setup program.