



## Extension Grip EG-E1

*EASY  
ACCESS*

Painless Battery & Memory Card swaps


# Extension Grip

Card slot/battery compartment cover lock

Card slot/battery compartment cover

Tripod socket

Attach/detach dial



# Extension Grip



# Extension Grip

**Red**



**Black**



**Blue**

