












# Menu Route Map




## Adjustment/Maintenance




## Function Settings




## Menu Route Map




Settings marked with "\*" may not be displayed depending on the model you are using, options, or other setting items.





100% 90% 80% 70% 60% 50% 40% 30% 20% 10% 0%





Settings marked with "\*" may not be displayed depending on the model you are using, options, or other setting items.



100




Settings marked with "" may not be displayed depending on the model you are using, options, or other setting items.



— 1200 dpi, 600 dpi

# Menu Route Map



Settings marked with "\*" may not be displayed depending on the model you are using, options, or other setting items.

