

Menu Route Map

NOTE

- Red color values indicate the default settings.
- The setting items or setting values with "*" may not be displayed depending on the availability of the optional accessories and other settings.

See the User's Guide for details on settings.

[Setup] Menu

Control Menu

- Sleep Mode
 - High (Deep Sleep)
 - Mid (Printer Sleep)
 - Low (Panel Sleep)
 - Off
- Sleep Even if Error
 - Off
 - On
- Deep Sleep Eco Prior
 - Off
 - On
- Auto Sleep Time
 - 5 min.
 - 10 min.
 - 15 min.
 - 30 min.
 - 60 min.
 - 180 min.
- Sleep When Using USB*
 - Do Not Allow
 - Allow
- Timer Settings
 - Wake Up Timer
 - Off
 - On
 - Wake Up Time
 - 00:00 AM/PM to 12:00 PM to 11:59 AM/PM (00:00 to 12:00 to 23:59)
 - Auto Reset Time
 - Off
 - 10 sec.
 - 20 sec.
 - 30 sec.
 - 40 sec.
 - 50 sec.
 - 1 min.
 - 2 min.
 - 3 min.
 - 4 min.
 - 5 min.
 - 6 min.
 - 7 min.
 - 8 min.
 - 9 min.
 - Sleep Timer
 - Off
 - On
 - Sleep Time
 - 00:00 AM/PM to 12:00 PM to 11:59 AM/PM (00:00 to 12:00 to 23:59)
- Warning Step
 - Toner Cart. Warning
 - Continue Printing
 - Stop Printing
- Auto Skip Error
 - Off
 - On
- Language
 - Čeština
 - Dansk
 - Deutsch
 - English
 - Español
 - Français
 - Italiano
 - Magyar
 - Nederlands
 - Norsk
 - Polski
 - Português
 - Русский
 - Suomi
 - Svenska

- Türkçe
- 中文 (简体)
- 한국어
- Alarm
 - Off
 - On
- Show Warnings
 - Toner Cart. Warning
 - Off
 - On
 - Drawer Empty
 - Off
 - On
 - E-Mail Trans. Error
 - Off
 - On
- Date/Time Settings
 - Date
 - 01/01 2001 to 12/31 2030
 - 12/24 Hour Clock
 - 12 Hour (AM/PM)
 - 24 Hour
 - Time
 - 00:00:00 AM/PM to 11:59:59 AM/PM (00:00:00 to 23:59:59)
 - Daylight Savings
 - DST Settings: Off, On
 - Start Date/Time: Month, Week, Day, Time
 - End Date/Time: Month, Week, Day, Time
 - Time Zone
 - GMT-12:00 to GMT-05:00 to GMT+12:00
- Main Pwr Quick Start
 - Off
 - On
- SD Card*
 - Off
 - On
- Interrupt Print*
 - Off
 - On
- Sec. Print Del. Time*
 - 1 hr.
 - 2 hr.
 - 3 hr.
 - 6 hr.
 - 12 hr.
 - 24 hr.
- Secure Job Log*
 - Off
 - On
- USB-Connected PC OS
 - Mac OS
 - Windows
 - Other
- PDL Selection (PnP)
 - UFR II
 - UFR II (V4)
 - PCL6
 - PCL6 (V4)
 - PS3
 - XPS (Direct)
- Mng. Settings
 - Settings Key Lock
 - Off
 - On
- RMT-SW
 - Off
 - On
- Adjust Screen
 - Contrast
 - 3 to 0 to +3
 - Backlight Brightness
 - Off
 - Level 1
 - Level 2
 - Level 3

- Animated Instruction
 - Off
 - On
- Show Toner Gauge
 - Off
 - On
- Set. Comp. Notify
 - Off
 - 1 sec.
 - 2 sec.
 - 3 sec.
- Scrolling Speed
 - Slow
 - Normal
 - Fast

Paper Source

- Paper Source
 - Auto
 - Multi-Purpose Tray
 - Drawer 1
 - Drawer 2*
 - Drawer 3*
 - Drawer 4*
- MP Tray Paper Size
 - A6
 - A5
 - A5R
 - B5
 - A4
 - LTR
 - LGL
 - EXEC
 - Free Size
 - Custom Size
 - Custom Size R
 - Postcard
 - Reply Postcard
 - 4on1 Postcard
 - Env. Nagagata3
 - Env. Younaga 3
 - Env. ISO-C5
 - Env. Monarch
 - Env. No.10
 - Env. DL
 - India-LGL
 - Index Card
 - STMT
 - FLSC
 - 16K
- Drawer N Paper Size (N=1, 2, 3, 4)*
 - A6
 - A5
 - A5R
 - B5
 - A4
 - LTR
 - LGL
 - EXEC
 - Free Size
 - Custom Size
 - Custom Size R
 - India-LGL
 - STMT
 - FLSC
 - 16K
- Standard Paper Size
 - A6
 - A5
 - B5
 - A4
 - LTR
 - LGL
 - EXEC
 - Postcard

- Reply Postcard
- 4on1 Postcard
- Env. Nagagata3
- Env. Younaga 3
- Env. ISO-C5
- Env. Monarch
- Env. No.10
- Env. DL
- India-LGL
- Index Card
- STMT
- FLSC
- 16K
- MP Tray Priority**
 - Off
 - On
- MP Tray for Mix Ppr.**
 - Off
 - On
- Auto Select Drawer**
 - Do Not Use
 - Use
- Default Paper Type**
 - Plain
 - Plain L
 - Plain L2
 - Plain L3
 - Heavy 1
 - Heavy 2
 - Heavy 3
 - Heavy 4
 - Postcard
 - Envelope
 - Envelope H
 - Labels
 - Bond 1
 - Bond 2
 - Bond 3
- MP Tray Paper Type**
 - Plain
 - Plain L
 - Plain L2
 - Plain L3
 - Heavy 1
 - Heavy 2
 - Heavy 3
 - Heavy 4
 - Postcard
 - Envelope
 - Envelope H
 - Labels
 - Bond 1
 - Bond 2
 - Bond 3
- Drawer N Paper Type (N=1, 2, 3, 4)***
 - Plain
 - Plain L
 - Plain L2
 - Plain L3
 - Heavy 1
 - Heavy 2
 - Bond 1
 - Bond 2
 - Bond 3
- Manual 2-Sided (MP)**
 - 1st Side
 - 2nd Side
- 2-Sided Printing**
 - Off
 - On

Network

- TCP/IP Settings**
 - IPv4 Settings**
 - IPv4: Off, **On**
 - IP Mode: **Auto**, Manual
 - Protocol*
 - Use DHCP: Off, **On**
 - Use BOOTP: **Off**, On
 - Use RARP: **Off**, On

- Auto IP*: Off, **On**
- IP Address Settings**
 - IP Address: **0.0.0.0** to 255.255.255.255
 - Subnet Mask: **0.0.0.0** to 255.255.255.255
 - Gateway Address: **0.0.0.0** to 255.255.255.255
- DNS**
 - Primary Address: **0.0.0.0** to 255.255.255.255
 - Secondary Address: **0.0.0.0** to 255.255.255.255
- mDNS Settings***
 - mDNS: Off, **On**
 - mDNS Name*
- DHCP Option**
 - Acquire Host Name: Off, **On**
 - DNS Dynamic Update: **Off**, On
- IPv6 Settings**
 - IPv6: **Off**, On
 - mDNS Settings***
 - mDNS: Off, **On**
 - Use IPv4 Name (mDNS)*: Off, **On**
 - mDNS Name*
- WINS Resolution**
 - Off
 - On
- FTP**
 - FTP Print: **Off**, On
 - Allow Set. via FTP: **Off**, On
- LPD Settings**
 - LPD Print: Off, **On**
 - RX Timeout*: 1 to **60** (min.)
- RAW Settings**
 - RAW Print: Off, **On**
 - RX Timeout*: 1 to **60** (min.)
- IPP Print**
 - Off
 - On**
- WSD**
 - WSD Print: Off, **On**
 - WSD Browsing*: Off, **On**
 - Multicast Discovery: Off, **On**
- HTTP**
 - Off
 - On**
- Proxy Settings**
 - Proxy: **Off**, On
 - Server Address*
 - Port Number*: 1 to **80** to 65535
 - Same Domain*: Use Proxy, **Do Not Use Proxy**
 - Proxy Authentication*: **Off**, On
 - User Name*
 - Password*
- SNTP**
 - Off
 - On
- Discovery Response**
 - Off
 - On**
- IPSec**
 - Off
 - On
- Sleep Notif. Set.**
 - Sleep Mode Notif.: Off, **On**
 - Port Number*: 1 to **11427** to 65535
 - Routers to Traverse*: 0 to **3** to 254
 - Notif. Interval*: 60 to **600** to 65535
- Mopria**
 - Off
 - On**
- Google Cloud Print**
 - Use Cloud Print: Off, **On**
 - Registration Status
- SMB***
 - SMB Server**
 - Off
 - On
 - SMB Print***
 - Off
 - On
- SNMP Settings**
 - SNMPv1 Settings**
 - SNMPv1: Off, **On**
 - Dctd. Community Set.
 - Dctd. Community: Off, Read/Write, **Read Only**

- SNMPv3 Settings**
 - SNMPv3: **Off**, On
 - User Settings N (N=1, 2, 3, 4, 5)*
 - Auth. Password
 - Encryption Password
- Rjct Packet in Sleep**
 - Off
 - On
- Spooler***
 - Off
 - On
- Receive in Parallel**
 - Off
 - On**
- Wait Time at Startup**
 - 0 to 300 (sec.)
- Remote UI Settings**
 - Remote UI**
 - Off
 - On**
 - RUI Access Sec. Set.**
 - Off
 - On
 - TLS***
 - Off
 - On
- Ethernet Driver**
 - Auto Detect**
 - Off
 - On**
 - Communication Mode***
 - Half Duplex**
 - Full Duplex
 - Ethernet Type***
 - 10 Base-T**
 - 100 Base-TX
 - 1000 Base-T
- Sleep Mode Priority**
 - Optimal Balance**
 - Exit Speed
 - Energy Saving
- IEEE802.1X**
 - Off
 - On
- Address Filter**
 - Off
 - On**
- MAC Address**
 - (Display only)
- E-Mail Print Set.**
 - POP3 RX Interval**
 - 0 to 90 (min.)
 - POP3 RX**
 - Off
 - On
 - SMTP RX**
 - Off
 - On
- Monitoring Service**
 - Comm. Test**
 - Comm. Log**
 - (Display only)
- Init. Network Set.**

Layout

- Number of Copies**
 - 1 to 9999
- Offset Y**
 - 1.97 to **0.00** to +1.97 (inches)
 - (-50.0 to **0.0** to +50.0 (mm))
- Offset X**
 - 1.97 to **0.00** to +1.97 (inches)
 - (-50.0 to **0.0** to +50.0 (mm))
- Binding Location**
 - Long Edge**
 - Short Edge
- Gutter**
 - 1.97 to **0.00** to +1.97 (inches)
 - (-50.0 to **0.0** to +50.0 (mm))
- Alternative Method**
 - Off
 - On**

Print Quality

- Resolution
 - 600 dpi**
 - 1200 dpi
- Image Refinement*
 - Off
 - On**
- Toner Save
 - Off**
 - On
- Density*
 - 8 to **0** to +8
- Density (Fine Adj)*
 - High
 - 8 to **0** to +8
 - Medium
 - 8 to **0** to +8
 - Low
 - 8 to **0** to +8
- Halftones
 - Text
 - Resolution**
 - Gradation
 - Color Tone
 - High Resolution
 - Graphics
 - Resolution
 - Gradation
 - Color Tone**
 - High Resolution
 - Image
 - Resolution
 - Gradation
 - Color Tone**
 - High Resolution
- Reduce Quality
 - Continue Printing**
 - Stop Printing
- Adj. Prt. Line Width
 - 7 to **0** to +8

Interface

- Interface Selection
 - USB
 - Off
 - On**
 - Network
 - Off
 - On**
 - USB Adv. Functions
 - Adv. Func. Settings: **Meap Priority**, USB Over NW Priority
 - USB Storage Device
 - MEAP Driver: **Off**, On
- Timeout
 - Timeout
 - Off
 - On**
 - Timeout Time*
 - 5 to **15** to 300 (seconds)
- Connection Recog.
 - Off
 - On**
- Extended RX Buffer
 - Off
 - On**

User Maintenance

- Adj. Print Position
 - Common
 - Offset Y (2-Sided)
 - -0.20 to **0.00** to +0.20 (Inches)
 - (-5.0 to **0.0** to +5.0 (mm))
 - Offset X (2-Sided)
 - -0.20 to **0.00** to +0.20 (Inches)
 - (-5.0 to **0.0** to +5.0 (mm))
 - Multi-Purpose Tray
 - Offset Y (MP Tray)
 - -0.20 to **0.00** to +0.20 (Inches)
 - (-5.0 to **0.0** to +5.0 (mm))
 - Offset X (MP Tray)
 - -0.20 to **0.00** to +0.20 (Inches)
 - (-5.0 to **0.0** to +5.0 (mm))

- Drawer 1 to 4*
 - Offset Y (Drawer 1 to 4)
 - -0.20 to **0.00** to +0.20 (Inches)
 - (-5.0 to **0.0** to +5.0 (mm))
 - Offset X (Drawer 1 to 4)
 - -0.20 to **0.00** to +0.20 (Inches)
 - (-5.0 to **0.0** to +5.0 (mm))
- Recovery Printing
 - Off
 - On**
- Check Paper Size
 - Off**
 - On
- Substitute Size
 - Off**
 - On
- Short Edge Fd. Prty.
 - Off**
 - On
- Sp. Transfer Mode
 - Off**
 - On
- Special Print Mode A
 - Off
 - Mode 1**
 - Mode 2
 - Mode 3
 - Mode 4
- Adj. Scndry Transfer
 - Off**
 - On
- Wrinkle Correction
 - Off**
 - On
- Afterimage Corr.
 - Off**
 - On
- Sp. Transfer Mode 2
 - Off**
 - On
- Special Deliv. Mode
 - Off**
 - On
- Improve Toner Fixing
 - Off**
 - On
- SD Card Maintenance*
 - Format
 - Completely Del. Data
- Special Print Mode
 - Curl Correction
 - Off**
 - On
 - Reduce Ppr. Sticking
 - Off**
 - On
 - Rough Paper Adj.
 - Off**
 - On
 - Incr Pcard Fix. Qlty
 - Off**
 - On
- Special Print Adj. C
 - Off**
 - On
- Barcode Adj. Mode
 - Off**
 - Mode 1
 - Mode 2
 - Mode 3
 - Mode 4
- Update Firmware
 - USB
 - Network
- Paper Feed Method
 - Multi-Purpose Tray
 - Speed Priority**
 - Print Side Priority
 - Drawer 1 to 4*
 - Speed Priority**
 - Print Side Priority
- Show Job List
 - Off
 - On**

- Import/Export Set.
 - IMPORT
 - EXPORT
- Notify to Clean
 - Off**
 - On
- Clean. Notif. Timing*
 - 1000** to 50000 (pages)
- Toner Check Timing
 - Default**
 - Custom
- Spec Tnr Chk Timing*
 - 1 to **20** to 99 (%)

Print Mode

- Auto Mode Selection
 - Auto Selection**
 - PCL
 - PS
 - PDF
 - XPS
- Auto Select
 - PCL
 - Off
 - On**
 - PS
 - Off
 - On**
 - PDF
 - Off
 - On**
 - XPS
 - Off
 - On**
- Mode Priority
 - None**
 - PCL
 - PS
 - PDF
 - XPS

UFR II

- Paper Save
 - Off
 - On**

PCL

- Paper Save
 - Off**
 - On
- Orientation
 - Portrait**
 - Landscape
- Font Number
 - 0** to 104
- Point Size*
 - 4.00 to **12.00** to 999.75 point
- Pitch*
 - 0.44 to **10.00** to 99.99 cpi
- Form Lines
 - 5 to **60** to 128 lines
- Character Code
 - PC8**
 - ROMAN8
 - ROMAN9
 - ISOL1
 - ISOL2
 - ISOL5
 - ISOL6
 - ISOL9
 - PC775
 - PC8DN
 - PC850
 - PC852
 - PC858
 - PC8TK
 - PC1004
 - WINL1
 - WINL2
 - WINL5
 - WINBALT
 - DESKTOP

- PSTEXT
- LEGAL
- ISO4
- ISO6
- ISO11
- ISO15
- ISO17
- ISO21
- ISO60
- ISO69
- WIN 30
- MCTEXT
- PC864
- ARABIC8
- WINARB
- PC866
- ISOCYR
- WINCYR
- PC851
- GREEK8
- ISOGRK
- PC8GRK
- WINGRK
- PC862
- HEBREW7
- HEBREW8
- ISOHEB
- Custom Size
 - Do Not Set
 - Set
- Unit of Measurement*
 - Millimeters
 - Inches
- X Dimension*
 - 3.00 to **8.50 in.** (76.2 to **215.9 mm**)
- Y Dimension*
 - 5.00 to **14.00 in.** (127.0 to **355.6 mm**)
- Append CR to LF
 - Yes
 - No
- Enlarge A4 Prt Width
 - Off
 - On
- BarDIMM*
 - Enable
 - Disable
- FreeScape*
 - Off
 - ~
 - ^
 - #
 - \$
 - /
 - \
 - ?
 - {
 - }
 - |

Imaging

- Image Orientation
 - Auto
 - Vertical
 - Horizontal
- Zoom
 - Off
 - Auto
- Print Position
 - Auto
 - Center
 - Top Left
- TIFF Spooler
 - Off
 - On
- Show Warnings
 - Off
 - Print
 - Panel
- Print E-Mail Text
 - Off
 - On

- Limit E-Mail Print*
 - Off
 - On
- Enlarge Print Area
 - Off
 - On
- Halftones
 - Resolution
 - Gradation
 - High Resolution
- Grayscale Conversion
 - sRGB
 - NTSC
 - Uniform RGB

XPS

- Halftones
 - Text
 - Resolution
 - Gradation
 - High Resolution
 - Graphics
 - Resolution
 - Gradation
 - High Resolution
 - Image
 - Resolution
 - Gradation
 - High Resolution
- Grayscale Conversion
 - Text
 - sRGB
 - NTSC
 - Uniform RGB
 - Graphics
 - sRGB
 - NTSC
 - Uniform RGB
 - Image
 - sRGB
 - NTSC
 - Uniform RGB
- Compressed Img Mode*
 - Image Priority
 - Output Priority
- Compressed Img Output
 - Output
 - Display Error

PDF

- Fit to Paper Size
 - Off
 - On
- Enlarge Print Area
 - Off
 - On
- N on 1
 - Off
 - 2 on 1
 - 4 on 1
 - 6 on 1
 - 8 on 1
 - 9 on 1
 - 16 on 1
- Comment Print
 - Off
 - Auto
- Halftones
 - Text
 - Resolution
 - Gradation
 - High Resolution
 - Graphics
 - Resolution
 - Gradation
 - High Resolution
 - Image
 - Resolution
 - Gradation
 - High Resolution

Grayscale Conversion

- sRGB
- NTSC
- Uniform RGB

PS

- Job Timeout
 - 0 to 3600 seconds
- Print PS Errors
 - Off
 - On
- Halftones
 - Text
 - Resolution
 - Gradation
 - High Resolution
 - Graphics
 - Resolution
 - Gradation
 - High Resolution
 - Image
 - Resolution
 - Gradation
 - High Resolution
- Grayscale Conversion
 - sRGB
 - NTSC
 - Uniform RGB

MEAP Settings

- Select Def. Screen
 - Print Screen
 - MEAP

Check Counter

- 101: Total 1
 - (Display only)

Initialize Menu

[Utility] Menu

- Check Counter
 - 101: Total 1
 - (Display only)
- Configuration Page
- Network Status Print
- Consmb. Status Prt.
- IPSec Policy List
- PCL Utility
 - Font List
- PS Utility
 - Configuration Page
 - Font List
- Cleaning
 - A4
 - LTR
- E-Mail Print Utility
 - Received E-Mail
 - E-Mail RX Log List
- Printing Pos. Print
- Page Count List
- Counter Report
- Print MEAP Sys. Info
- Cartridge Log Print
- Serial Number
 - (Display only)
- Consumables Info.
 - Paper Information
 - Multi-Purpose Tray: (Display only)
 - Drawer 1: (Display only)
 - Drawer 2*: (Display only)
 - Drawer 3*: (Display only)
 - Drawer 4*: (Display only)

- Toner Cart. Model
 - (Display only)
- Remaining Toner
 - (Display only)

[Job] Menu

- Encrypted Print*
- Secured Print*
- Stored Job List*
- Stored Job Print*
- Job Print Log*
- Stored Job Print Log*
- Report Print Log*
- E-Mail Print Log*

[Reset] Menu

- Soft Reset (Hard Reset)
- Form Feed
- Shut Down

[Select Feeder] Menu

- Paper Source
 - Auto**
 - Multi-Purpose Tray
 - Drawer 1
 - Drawer 2*
 - Drawer 3*
 - Drawer 4*
- MP Tray Paper Size
 - A6
 - A5
 - A5R
 - B5
 - A4
 - LTR**
 - LGL
 - EXEC
 - Free Size
 - Custom Size
 - Custom Size R
 - Postcard
 - Reply Postcard
 - 4on1 Postcard
 - Env. Nagagata3
 - Env. Younaga 3
 - Env. ISO-C5
 - Env. Monarch
 - Env. No.10
 - Env. DL
 - India-LGL
 - Index Card
 - STMT
 - FLSC
 - 16K
- Drawer N Paper Size (N=1, 2, 3, 4)*
 - A6
 - A5
 - A5R
 - B5
 - A4
 - LTR**
 - LGL
 - EXEC
 - Free Size
 - Custom Size
 - Custom Size R
 - India-LGL
 - STMT
 - FLSC
 - 16K

- Standard Paper Size
 - A6
 - A5
 - B5
 - A4
 - LTR**
 - LGL
 - EXEC
 - Postcard
 - Reply Postcard
 - 4on1 Postcard
 - Env. Nagagata3
 - Env. Younaga 3
 - Env. ISO-C5
 - Env. Monarch
 - Env. No.10
 - Env. DL
 - India-LGL
 - Index Card
 - STMT
 - FLSC
 - 16K
- MP Tray Priority
 - Off**
 - On
- MP Tray for Mix Ppr.
 - Off**
 - On
- Auto Select Drawer
 - Do Not Use
 - Use**
- Default Paper Type
 - Plain**
 - Plain L
 - Plain L2
 - Plain L3
 - Heavy 1
 - Heavy 2
 - Heavy 3
 - Heavy 4
 - Postcard
 - Envelope
 - Envelope H
 - Labels
 - Bond 1
 - Bond 2
 - Bond 3
- MP Tray Paper Type
 - Plain
 - Plain L
 - Plain L2
 - Plain L3
 - Heavy 1
 - Heavy 2
 - Heavy 3
 - Heavy 4
 - Postcard
 - Envelope
 - Envelope H
 - Labels
 - Bond 1
 - Bond 2
 - Bond 3
 - Mixed Types**
- Drawer N Paper Type (N=1, 2, 3, 4)*
 - Plain
 - Plain L
 - Plain L2
 - Plain L3
 - Heavy 1
 - Heavy 2
 - Bond 1
 - Bond 2
 - Bond 3
 - Mixed Types**
- Manual 2-Sided (MP)
 - 1st Side**
 - 2nd Side
- 2-Sided Printing
 - Off**
 - On