

LBP6670dn Menu

Job	Job Print Log List	No, Yes			
	Report Print Log	No, Yes			
	E-mail Print Log	No, Yes			
Settings (Setup)	Control Menu	Sleep Mode	Off, Panel Off, Deep Sleep		
		Sleep Even if Error	Off, On		
		Sleep Migration Time	5, 10, 15, 30, 60, 180 minutes		
		Time Settings	Wake Up Timer	Off , On	
			Wake Up Time	12:00 (U/D keys: Adjust Value R/L Keys: Move Field)	
			Sleep Mode Timer	Off , On	
			Sleep Mode Time		
		Warning Step	Toner Cart. Warning	Continue Printing , Stop Printing	
		Auto Continue	Off, On		
		Panel Language	English , Español, Français, Italiano, 中文, 한국의		
		Alarm	Off, On		
		Show Warnings	Toner Cart. Warning	Off, On	
			Drawer Empty	Off, On	
			E-Mail Trans. Error	Off, On	
		Date/Time Settings	Date	03/01/2012 (U/D keys: Adjust Value R/L Keys: Move Field)	
			Time (24 hour)	12:00:00 (U/D keys: Adjust Value R/L Keys: Move Field)	
			Daylight Savings	(Settings effective next time main power is turned ON. Press OK to continue.)	
			Time Zone	(Settings effective next time main power is turned ON. Press OK to continue.)	
		Select PDL (PnP)	(Settings effective next time main power is turned ON. Press OK to continue.)		
		Mng. Settings	Settings Key Lock	If the settings key is locked, it can only be unlocked from the remote UI. Press OK to continue.	
		Adjust Screen	Contrast	0 (-3 Dark - +3 Light)	
			Backlight Brightness	Off, Level 1, Level 2, Level 3	
		Animated Instruction	Off, On		
		Show Toner Gauge	Off, On		
		Set. Comp. Notify	Off, 1 second, 2 seconds, 3 seconds		
		Paper Source	Paper Source	Auto , Drawer 1, Multi-Purpose Tray	
			MP Tray Paper Size	A6, A5, B5, A4, LTR , LGL, EXEC, Mixed Sizes, Custom Size, Custom Size R, Env. ISO-C5, Env. Monarch, Env. No.10, Env. DL, Env. ISO-B5, Index Card, STMT, 16K	
			MP Tray Priority	Off, On	
			Drawer 1 Size	A6, A5, B5, A4, LTR , LGL, EXEC, Mixed Sizes, Custom Size, Custom Size R, 16K	
			Standard Paper Size	A6, A5, B5, A4, LTR , LGL, EXEC, Env. ISO-C5, Env. Monarch, Env. No.10, Env. DL, Env. ISO-B5, Index Card, STMT, 16K	
			Diff. Paper Tray	Off, On	
			Auto Selection	Multi-Purpose Tray	Off, On
				Drawer 1	Off, On
			Default Paper Type	Plain , Plain L, Heavy 1, Heavy 2, Transparency, Envelope, Labels	
			2-Sided Printing	Off, On	
		Network	(Settings effective next time main power is turned ON. Press OK to continue.)		
		Layout	Copies	1 (1-9999)	
			Offset Y	0.0 (-50.0 - +50.0)	
			Offset X	0.0 (-50.0 - +50.0)	
			Binding Location	Long Edge, Short Edge	
			Gutter	0.0 (-50.0 - +50.0)	
			Alternative Method	Off, On	
	Quality	Resolution	600 dpi , 1200 dpi		
		Image Refinement	Off, On		
		Toner Save	Off, On		
		Density	0 (-8 Light - +8 Dark)		
		Density (Fine Adj)	High , Mid, Low		
		Halftones	Text , Graphics, Image		
		Reduce Quality	Continue Printing , Stop Printing		
	Interface	Interface Selection	(Settings effective next time main power is turned ON. Press OK to continue.)		
		Timeout	Timeout	Off, On	
			Timeout Time	15 seconds (5-300)	
		Connection Recog.	(Settings effective next time main power is turned ON. Press OK to continue.)		
	User Maintenance	Set to Offline			
	Print Mode	Auto Mode Selection	Auto Selection , PCL, PS, PDF		
		Auto Select	PCL	Off, On	

		PS	Off, On
		PDF	Off, On
	Mode Priority	None, PCL, PS, PDF	
UFR II	Paper Save	Off, On	
PCL	Paper Save	Off, On	
	Orientation	Portrait, Landscape	
	Font number	0 (0-54)	
	Pitch	10.00 cpi (0.44-99.99)	
	Form Lines	64 lines (5-128)	
	Character Code	PC8, ROMAN8, ROMAN9, ISOL1, ISOL2, ISOL5, ISOL6, ISOL9, PC775, PC8DN, PC850, PC852, PC858, PC8TK, PC1004, WINL1, WINL2, WINL5, WINBAL, DESKTOP, PSTEXT, LEGAL, ISO4, ISO6, ISO11, ISO15, ISO17, ISO21, ISO60, ISO69, WIN 30, MCTEXT	
	Custom Size	Do Not Set , Set	
	Append CR to LF	Yes, No	
	Enlarge A4 Prt Width	Off , On	
Imaging	Image Orientation	Auto , Vertical, Horizontal	
	Zoom	Off , Auto	
	Print Position	Auto , Center, Top Left	
	Show Warnings	Off, Print , Panel	
	Print E-mail Text	Off, On	
	Limit E-Mail Print	Off , On	
	Enlarge Print Area	Off , On	
	Halftones	Resolution, Gradation , High Resolution	
	Grayscale Conversion	sRGB, NTSC , Uniform RGB	
PDF	Fit to page	Off , On	
	Enlarge Print Area	Off , On	
	N on 1	Off , 2 on 1, 4 on 1, 6 on 1, 8 on 1, 9 on 1, 16 on 1	
	Comment Print	Off, Auto	
	Halftones	Text	Resolution , Gradation, High Resolution
		Graphics	Resolution , Gradation, High Resolution
		Image	Resolution , Gradation, High Resolution
	Grayscale Conversion	sRGB, NTSC , Uniform RGB	
	Dot Gain Adjustment	-10%, -5%, Standard , +5%, +10%	
PS	Job Timeout	0 seconds (0-3600)	
	Print PS Errors	Off , On	
	Halftones	Text	Resolution , Gradation, High Resolution
		Graphics	Resolution , Gradation, High Resolution
		Image	Resolution , Gradation, High Resolution
	Grayscale Conversion	sRGB, NTSC , Uniform RGB	
	Dot Gain Adjustment	-10%, -5%, Standard , +5%, +10%	
Check Counter	(Number)		
Initialize Menu	No , Yes		
Reset	Soft Reset	No , Yes	
	Form Feed	No , Yes	
	Shut Down	No , Yes	
Utility	Check Counter	(Number)	
	Configuration Page	No , Yes	
	Network Status Print	No , Yes	
	PCL Utility	Font List	No , Yes
	PS Utility	Configuration Page	No , Yes
		Font List	No , Yes
	Cleaning	A4	No , Yes
		LTR	No , Yes
	E-Mail Print Utility	Received E-Mails	No , Yes
		Received E-Mail List	No , Yes
	Printing Pos. Print	No , Yes	
	Counter Report	No , Yes	
	Total Printed Pages	(Number)	
Consumables	Paper Information	Muti-Purpose Tray, Drawer 1	
	Toner Cart. Model	Cartridge 719/719H	
	Remaining Toner	7-100%	