

Menu Route Map

Preferences

- Display Settings**
 - Language
 - English, French, Portuguese, Spanish
 - Contrast
 - 2 to 0 to +2
 - Invert Screen Colors
 - Off, On
 - mm/Inch Entry Switch
 - mm, Inch
 - Gram/Pound Switch
 - Gram, Pound
 - Message Display Time
 - 1 to 2 to 5 (sec.)
 - Scrolling Speed
 - Slow, Normal, Fast
 - Cursor Movement
 - Auto, Manual
- Toner Saver Mode**
 - Copy
 - Off, On
- Paper Feed Method Switch**
 - Multi-Purpose Tray
 - Print Speed Priority, Print Side Priority
 - Drawer 1
 - Print Speed Priority, Print Side Priority

Adjustment/Maintenance

- Special Processing**
 - Special Mode U
 - Off, On
 - Special Mode V
 - Off, Mode 1, Mode 2, Mode 3
 - Special Mode Z
 - Off, Mode 1, Mode 2, Mode 3, Mode 4
 - Special Mode B
 - Off, Mode 1, Mode 2, Mode 3
 - Special Mode C
 - Off, On
 - Special Mode D
 - Copy: Off, On
 - Print: Off, On
 - Special Mode I
 - Off, On
 - Special Mode J
 - Off, On
 - Special Mode K
 - Off, On
- Clean Fixing Unit**

Timer Settings

- Quiet Mode Time Settings**
 - Start Time
 - Off, On - AM, PM
 - End Time
 - Off, On - AM, PM
- Time & Date Settings**
 - Date Display Type
 - YYYY MM/DD, MM/DD/YYYY, DD/MM YYYY
 - 12/24 Hour Clock
 - 12 Hour (AM/PM), 24 Hour
 - Current Time Settings
 - Daylight Savings
 - Off
 - On
 - Start (M/W/D), End (M/W/D)
- Auto Sleep Time**
 - 5 to 240 (min.)
- Auto Reset Time**
 - 0=Off, 1 to 2 to 9 (min.)
- Auto Offline Time**
 - 0=Off, 1 to 5 to 60 (min.)

System Settings

- System Manager Information Settings**
 - System Manager PIN
 - Up to seven digits
 - System Manager Name
 - Up to 32 characters
- Device Information Settings**
 - Device Name
 - Up to 32 characters
 - Location
 - Up to 32 characters
- Select Country/Region**
 - United States (US), Canada (CA), Brazil (BR), Mexico (MX), Other
- USB Device On/Off**
 - Off, On
- Select PDL (Plug-n-Play)**
 - USB
 - UFRII LT, UFRII LT(XPS)
- Update Firmware**
- Initialize System Settings**
 - System Manager Information Settings
 - Device Information Settings
 - USB Device On/Off
 - Select PDL (Plug-n-Play)
 - Initialize All

Copy Settings

- Change Defaults**
- Correct Density**
 - 4 to 0 to +4

Initialize Menu

- Preferences
- Timer Settings
- Copy Settings
- Special Processing
- Initialize All