

Menu Route Map

NOTE

- Red color values indicate the default settings.
- The setting items or setting values with "*" may not be displayed depending on the availability of the optional accessories and other settings.

See the e-Manual for details on settings.

[Setup] Menu

Control Menu

- Sleep Mode
 - High (Deep Sleep)
 - Mid (Printer Sleep)
 - Low (Panel Sleep)
 - Off
- Sleep Even if Error
 - Off
 - On
- Sleep Migration Time
 - 5 minutes
 - 10 minutes
 - 15 minutes
 - 30 minutes
 - 60 minutes
 - 180 minutes
- Timer Settings
 - Wake Up Timer
 - Off
 - On
 - Wake Up Time
 - 00:00 AM/PM to 12:00 PM to 11:59 AM/PM (00:00 to 12:00 to 23:59)
 - Auto Reset Time
 - Off
 - 10 seconds
 - 20 seconds
 - 30 seconds
 - 40 seconds
 - 50 seconds
 - 1 minute
 - 2 minutes
 - 3 minutes
 - 4 minutes
 - 5 minutes
 - 6 minutes
 - 7 minutes
 - 8 minutes
 - 9 minutes
 - Sleep Mode Timer
 - Off
 - On
 - Sleep Mode Time
 - 00:00 AM/PM to 12:00 PM to 11:59 AM/PM (00:00 to 12:00 to 23:59)
 - Calibration Timer
 - Off
 - On
 - Calibration Time
 - 00:00 AM/PM to 12:00 PM to 11:59 AM/PM (00:00 to 12:00 to 23:59)
- Warning Step
 - Toner Cart. Warning
 - Continue Printing
 - Stop Printing
- Auto Continue
 - Off
 - On
- Panel Language
 - Deutsch
 - English
 - Español
 - Français
 - Italiano
 - 中文(简体)
 - 한국어
- Alarm
 - Off
 - On
- Show Warnings
 - Toner Cart. Warning
 - Off
 - On

- Check Fixing Unit
 - Off
 - On
- Check ITB Unit
 - Off
 - On
- Check Waste Tnr Ctn
 - Off
 - On
- Drawer Empty
 - Off
 - On
- E-Mail Trans. Error
 - Off
 - On
- Date/Time Settings
 - Date
 - 01/01/2001 to 31/12/2030
 - 12/24 Hour Clock
 - AM/PM
 - 24 Hour
 - Time
 - 00:00:00 AM/PM to 12:00:00 PM to 11:59:59 AM/PM (00:00:00 to 12:00:00 to 23:59:59)
 - Daylight Savings*
 - DST Settings: Off, On
 - Start Date/Time: Month, Week, Day, Time
 - End Date/Time: Month, Week, Day, Time
 - Time Zone*
 - GMT-12:00 to GMT+12:00
- SD Card*
 - Off
 - On
- Interrupt Print*
 - Off
 - On
- Sec. Print Del. Time*
 - 1 hour
 - 2 hours
 - 3 hours
 - 6 hours
 - 12 hours
 - 24 hours
- Secure Job Log*
 - Off
 - On
- Select PDL (PnP)*
 - UFR II
 - UFR II XPS*
 - PCL5c
 - PCL6
 - PS3
 - XPS (Direct)
- Mng. Settings
 - Settings Key Lock
 - Off
 - On
- Adjust Screen
 - Contrast
 - 3 Dark to 0 to +3 Light
 - Backlight Brightness
 - Off
 - Level 1
 - Level 2
 - Level 3
- Animated Instruction
 - Off
 - On
- Show Toner Gauge
 - Off
 - On
- Set. Comp. Notify
 - Off
 - 1 second
 - 2 seconds
 - 3 seconds

- Scrolling Speed
 - Slow
 - Normal
 - Fast

Paper Source

- Paper Source
 - Auto
 - Drawer 1
 - Drawer 2*
 - Multi-Purpose Tray
- MP Tray Paper Size
 - A6
 - A5
 - A5R
 - B5
 - A4
 - LTR
 - LGL
 - EXEC
 - Mixed Sizes
 - Custom Size
 - Custom Size R
 - Env. ISO-C5
 - Env. Monarch
 - Env. No.10
 - Env. DL
 - Index Card
 - STMT
 - FLSC
 - 16K
- MP Tray Priority
 - Off
 - On
- Drawer 1 Size
 - A6
 - A5
 - A5R
 - B5
 - A4
 - LTR
 - EXEC
 - Mixed Sizes
 - Custom Size
 - Custom Size R
 - STMT
 - 16K
- Drawer 2 Size
 - Mixed Sizes
 - Auto
 - Custom Size
 - Custom Size R
 - FLSC
 - 16K
- Standard Paper Size
 - A6
 - A5
 - B5
 - A4
 - LTR
 - LGL
 - EXEC
 - Env. ISO-C5
 - Env. Monarch
 - Env. No.10
 - Env. DL
 - Index Card
 - STMT
 - FLSC
 - 16K
- Diff. Paper Tray
 - Off
 - On

Auto Selection

- Multi-Purpose Tray
 - Off
 - On**
- Drawer 1
 - Off
 - On**
- Drawer 2*
 - Off
 - On**

Default Paper Type

- Plain**
- Plain L
- Plain L2
- Heavy 1
- Heavy 2
- Heavy 3
- Transparency
- Envelope
- Labels
- Rough

MP Tray Paper Type

- Plain
- Plain L
- Plain L2
- Heavy 1
- Heavy 2
- Heavy 3
- Transparency
- Envelope
- Labels
- Rough
- Mixed Types**

Drawer 1 Type

- Plain
- Plain L
- Plain L2
- Heavy 1
- Heavy 2
- Rough
- Mixed Types**

Drawer 2 Type*

- Plain
- Plain L
- Plain L2
- Heavy 1
- Heavy 2
- Heavy 3
- Rough
- Mixed Types**

Manual 2-Sided (MP)

- 1st Side**
- 2nd Side

2-Sided Printing

- Off**
- On

Network

TCP/IP Settings

- IPv4 Settings
 - IPv4: Off, **On**
 - IP Mode: Auto, **Manual**
 - Protocol*
 - Use DHCP: **Off**, On
 - Use BOOTP: **Off**, On
 - Use RARP: **Off**, On
 - IP Address Settings
 - IP Address: 0.0.0.0
 - Subnet Mask: 0.0.0.0
 - Gateway Address: 0.0.0.0
 - DNS
 - Primary Address: 0.0.0.0
 - Secondary Address: 0.0.0.0
 - DHCP Option
 - Acquire Host Name: Off, **On**
 - DNS Dynamic Update: **Off**, On
- IPv6 Settings
 - IPv6: **Off**, On
- WINS Resolution
 - Off**
 - On

- ARP/PING
 - Off
 - On**
- FTP
 - FTP Print: **Off**, On
 - FTP Settings: **Off**, On
- LPD Print
 - Off
 - On**
- RAW Print
 - Off
 - On**
- IPP Print
 - Off
 - On
- WSD
 - WSD Print: **Off**, On
 - WSD Browsing*: **Off**, On
 - Multicast Discovery: **Off**, On
- HTTP
 - Off
 - On**
- Proxy Settings*
 - Proxy: **Off**, On
 - Server Address*
 - Port Number*: 0 to **80** to 99999
 - Same Domain*: Use Proxy, **Do Not Use Proxy**
 - Proxy Authentication*: **Off**, On
 - User Name*
 - Password*
- SNTP
 - Off**
 - On
- Discovery Response
 - Off
 - On**
- IPSec
 - Off**
 - On

NetWare Settings

- NetWare
 - Off**
 - On
- Frame Type*
 - Auto Detect**
 - Ethernet II
 - Ethernet 802.2
 - Ethernet 802.3
 - Ethernet SNAP
- Print Service*
 - Bindery PServer
 - RPrinter
 - NDS PServer**
 - NPrinter

AppleTalk

- Off**
- On

SMB*

- SMB Server
 - Off**
 - On
- SMB Print
 - Off**
 - On

SNMP v. 1 Settings

- SNMP v. 1
 - Off
 - On**
- Dctd. Community Set.
 - Dctd. Community: Off, Read/Write, **Read Only**

SNMP v. 3 Settings

- SNMP v. 3
 - Off**
 - On
- User Settings 1 to User Settings 5*
 - Auth. Password
 - Encryption Password

Spooler*

- Off**
- On

Network Delay Time

- 0** to 300 seconds

Remote UI Settings

- Remote UI: Off, **On**
- SSL*: **Off**, On*

Ethernet Driver

- Auto Detect
 - Off
 - On**
- Communication Mode*
 - Half Duplex**
 - Full Duplex
- Ethernet Type*
 - 10 Base-T**
 - 100 Base-TX
 - 1000 Base-T

IEEE802.1X

- Off**
- On

Address Filter

- Off
- On**

MAC Address

- (Display only)

E-Mail Print Set.

- POP3 RX Interval
 - 0** to 90 (minutes)
- POP3 RX
 - Off**
 - On
- SMTP RX
 - Off**
 - On

Init. Network Set.

Layout

- Copies
 - 1** to 9999
- Offset Y/Offset X
 - 1.97 to **0.00** to +1.97 (in.)
- Binding Location
 - Long Edge**
 - Short Edge
- Gutter
 - 1.97 to **0.00** to +1.97 (in.)
- Alternative Method
 - Off
 - On**

Quality

- Gradation Level
 - High 1**
 - High 2
- Toner Save
 - Off**
 - On
- Density: C*
 - 8 Light to **0** to +8 Dark
- Density: M*
 - 8 Light to **0** to +8 Dark
- Density: Y*
 - 8 Light to **0** to +8 Dark
- Density: K*
 - 8 Light to **0** to +8 Dark
- Density C (Fine Adj)*
 - High
 - 8 Light to **0** to +8 Dark
 - Mid
 - 8 Light to **0** to +8 Dark
 - Low
 - 8 Light to **0** to +8 Dark
- Density M (Fine Adj)*
 - High
 - 8 Light to **0** to +8 Dark
 - Mid
 - 8 Light to **0** to +8 Dark
 - Low
 - 8 Light to **0** to +8 Dark
- Density Y (Fine Adj)*
 - High
 - 8 Light to **0** to +8 Dark
 - Mid
 - 8 Light to **0** to +8 Dark

- Low
 - 8 Light to **0** to +8 Dark
- Density K (Fine Adj)*
 - High
 - 8 Light to **0** to +8 Dark
 - Mid
 - 8 Light to **0** to +8 Dark
 - Low
 - 8 Light to **0** to +8 Dark
- Color Mode
 - Auto (Color/Black)**
 - Color
 - Black
- Halftones
 - Error Diffusion
 - Off**
 - On
 - Resolution/Grad.
 - Text: **Resolution**, Gradation
 - Graphics: Resolution, **Gradation**
 - Image: Resolution, **Gradation**
- Gray Compensation
 - Text
 - Off
 - On**
 - Graphics
 - Off
 - On**
 - Image
 - Off
 - On**
- CMS
 - CMS Selection
 - Printer**
 - Host
 - CMS/Gamma
 - Text: CMS, **Gamma**
 - Graphics: CMS, **Gamma**
 - Image: CMS, **Gamma**
 - RGB Source Profile
 - Text: **sRGB v3.0 (Canon)**, Canon HDTV gamma 1.5, Canon HDTV gamma 1.8, Canon HDTV gamma 2.4
 - Graphics: **sRGB v3.0 (Canon)**, Canon HDTV gamma 1.5, Canon HDTV gamma 1.8, Canon HDTV gamma 2.4
 - Image: **sRGB v3.0 (Canon)**, Canon HDTV gamma 1.5, Canon HDTV gamma 1.8, Canon HDTV gamma 2.4
 - Output Profile
 - Text: **Normal**, Photo
 - Graphics: **Normal**, Photo
 - Image: Normal, **Photo**
 - Matching Method
 - Text: Perceptual, **Saturation**, Colorimetric
 - Graphics: **Perceptual**, Saturation, Colorimetric
 - Image: **Perceptual**, Saturation, Colorimetric
 - Gamma Correction
 - Text: 1.0, **1.4**, 1.8, 2.2
 - Graphics: 1.0, **1.4**, 1.8, 2.2
 - Image: 1.0, **1.4**, 1.8, 2.2
- Gradation Settings
 - Gradation
 - Off**
 - Smooth 1
 - Smooth 2
 - Graphics
 - Off
 - On**
 - Image
 - Off
 - On**
- Advanced Smoothing
 - Advanced Smoothing
 - Off
 - Smooth 1**
 - Smooth 2
 - Graphics
 - Off**
 - On

- Text
 - Off
 - On**
- Toner Volume Corr.
 - Normal**
 - Gradation Priority
 - Text Priority
- Line Control
 - Resolution Priority**
 - Gradation Priority
- Reduce Quality
 - Continue Printing**
 - Stop Printing

- Interface
 - Interface Selection*
 - USB
 - Off
 - On**
 - Network
 - Off
 - On**
 - Timeout
 - Timeout
 - Off
 - On**
 - Timeout Time*
 - 5 to **15** to 300 seconds
 - Connection Recog.*
 - Off
 - On**
 - Extended RX Buffer*
 - Off**
 - On

- User Maintenance
 - Adj. Start Position
 - Offset Y (MP Tray)
 - 0.20 to **0.00** to +0.20 (in.)
 - Offset X (MP Tray)
 - 0.09 to **0.00** to +0.09 (in.)
 - Offset Y (Drawer 1)
 - 0.20 to **0.00** to +0.20 (in.)
 - Offset X (Drawer 1)
 - 0.09 to **0.00** to +0.09 (in.)
 - Offset Y (Drawer 2)*
 - 0.20 to **0.00** to +0.20 (in.)
 - Offset X (Drawer 2)*
 - 0.09 to **0.00** to +0.09 (in.)
 - Offset Y (2-Sided)
 - 0.20 to **0.00** to +0.20 (in.)
 - Offset X (2-Sided)
 - 0.09 to **0.00** to +0.09 (in.)
 - Recovery Printing
 - Off
 - On**
 - Check Paper Size
 - Off**
 - On
 - Substitute Size
 - Off**
 - On
 - Special Image Mode
 - Off**
 - Level 1
 - Level 2
 - SD Card Maintenance
 - Format
 - No**
 - Yes
 - Special Print Mode
 - Curl Correction
 - Off**
 - On
 - Smooth Plain Paper
 - Off**
 - On
 - Update Firmware
 - USB
 - Network
 - First Calibration
 - Off**

- After Jobs
 - Immediately
- Paper Feed Method
 - Multi-Purpose Tray
 - Speed Priority**
 - Print Side Priority
 - Drawer 1
 - Speed Priority**
 - Print Side Priority
 - Drawer 2*
 - Speed Priority**
 - Print Side Priority
- Adjust Standby Temp
 - Off**
 - Mode 1
 - Mode 2
 - Mode 3
- Show Job List
 - Off
 - On**
- IMPORT/EXPORT
 - EXPORT
 - IMPORT

- Print Mode
 - Auto Mode Selection
 - Auto Selection**
 - PCL
 - PS
 - PDF
 - XPS
 - Auto Select
 - PCL
 - Off
 - On**
 - PS
 - Off
 - On**
 - PDF
 - Off
 - On**
 - XPS
 - Off
 - On**
 - Mode Priority
 - None**
 - PCL
 - PS
 - PDF
 - XPS

- UFR II
 - Paper Save
 - Off
 - On**

- PCL
 - Paper Save
 - Off**
 - On
 - Orientation
 - Portrait**
 - Landscape
 - Font Number
 - 0** to 104
 - Point Size*
 - 4.00 to **12.00** to 999.75 point
 - Pitch*
 - 0.44 to **10.00** to 99.99 cpi
 - Form Lines
 - 5 to **60** to 128 lines
 - Character Code
 - PC8**
 - ROMAN8
 - ROMAN9
 - ISOL1
 - ISOL2
 - ISOL5
 - ISOL6
 - ISOL9
 - PC775
 - PC8DN

- PC850
- PC852
- PC858
- PC8TK
- PC1004
- WINL1
- WINL2
- WINL5
- WINBALT
- DESKTOP
- PSTEXT
- LEGAL
- ISO4
- ISO6
- ISO11
- ISO15
- ISO17
- ISO21
- ISO60
- ISO69
- WIN 30
- MCTEXT
- PC864
- ARABIC8
- WINARB
- PC866
- ISOCYR
- WINCYR
- PC851
- GREEK8
- ISOGRK
- PC8GRK
- WINGRK
- PC862
- HEBREW7
- HEBREW8
- ISOHEB
- Custom Size
 - Do Not Set
 - Set
- Unit of Measurement*
 - Millimeters
 - Inches
- X Dimension*
 - 3.00 to 8.50 in. (76.2 to 215.9 mm)
- Y Dimension*
 - 5.00 to 14.00 in. (127.0 to 355.6 mm)
- Append CR to LF
 - Yes
 - No
- Enlarge A4 Prt Width
 - Off
 - On
- BarDIMM*
 - Enable
 - Disable
- FreeScale*
 - Off
 - ~
 - "
 - #
 - \$
 - /
 - \
 - ?
 - {
 - }
 - |

- Imaging
 - Image Orientation
 - Auto
 - Vertical
 - Horizontal
 - Zoom
 - Off
 - Auto
 - Print Position
 - Auto
 - Center
 - Top Left

- Print Guarantee*
 - Off
 - On
- Show Warnings
 - Off
 - Print
 - Panel
- Print E-Mail Text
 - On
 - Off
- Limit E-Mail Print*
 - Off
 - On
- Enlarge Print Area
 - Off
 - On
- RGB Source Profile
 - sRGB v3.0 (Canon)
 - Canon HDTV gamma 1.5
 - Canon HDTV gamma 1.8
 - Canon HDTV gamma 2.4
- CMYK Sim. Profile
 - Euro Standard v1.00
 - JapanColor (Canon)
 - U.S. Web Coated v1.0
- Output Profile
 - Normal
 - Photo
- Matching Method
 - Perceptual
 - Saturation
 - Colorimetric
- Halftones
 - Resolution
 - Gradation
 - Error Diffusion
- Photo Corr (CL Only)*
 - Photo Optimizer PRO
 - Off
 - On
 - Red-Eye Correction
 - Red-Eye Correction: Off, On
 - Red-Eye Correct. Lv.*: Weak, Standard, Strong
 - Face Brightener
 - Face Brightener: Off, On
 - Face Brightener Lv.*: Weak, Standard, Strong
- Grayscale Conversion*
 - sRGB
 - NTSC
 - Uniform RGB

- XPS
 - Matching Mode
 - ICC Profile
 - Gamma
 - ICC Profile Settings
 - RGB Source Profile
 - Text: sRGB v3.0 (Canon), Canon HDTV gamma 1.5, Canon HDTV gamma 1.8, Canon HDTV gamma 2.4
 - Graphics: sRGB v3.0 (Canon), Canon HDTV gamma 1.5, Canon HDTV gamma 1.8, Canon HDTV gamma 2.4
 - Image: sRGB v3.0 (Canon), Canon HDTV gamma 1.5, Canon HDTV gamma 1.8, Canon HDTV gamma 2.4
 - Output Profile
 - Text: Normal, Photo
 - Graphics: Normal, Photo
 - Image: Normal, Photo
 - Matching Method
 - Text: Perceptual, Saturation, Colorimetric
 - Graphic: Perceptual, Saturation, Colorimetric
 - Image: Perceptual, Saturation, Colorimetric
 - Gamma Settings
 - Gamma Correction
 - Text: 1.0, 1.4, 1.8, 2.2
 - Graphics: 1.0, 1.4, 1.8, 2.2
 - Image: 1.0, 1.4, 1.8, 2.2
 - Photo Corr (CL Only)
 - Photo Optimizer PRO
 - Off
 - On

- Red-Eye Correction
 - Red-Eye Correction: Off, On
 - Red-Eye Correct. Lv.*: Weak, Standard, Strong
- Face Brightener
 - Face Brightener: Off, On
 - Face Brightener Lv.*: Weak, Standard, Strong
- Halftones
 - Error Diffusion: Off, On
 - Resolution/Grad.*
 - Text: Resolution, Gradation
 - Graphics: Resolution, Gradation
 - Image: Resolution, Gradation
- Gray Compensation
 - Text
 - Off
 - On
 - Graphics
 - Off
 - On
 - Image
 - Off
 - On
- Advanced Smoothing
 - Advanced Smoothing
 - Off
 - Smooth 1
 - Smooth 2
 - Graphics*
 - Off
 - On
 - Text*
 - Off
 - On
- Grayscale Conversion
 - Text
 - sRGB
 - NTSC
 - Uniform RGB
 - Graphics
 - sRGB
 - NTSC
 - Uniform RGB
 - Image
 - sRGB
 - NTSC
 - Uniform RGB

- PDF
 - Fit to Page
 - Off
 - On
 - Enlarged Print Area
 - Off
 - On
 - N on 1
 - Off
 - 2 on 1
 - 4 on 1
 - 6 on 1
 - 8 on 1
 - 9 on 1
 - 16 on 1
 - Comment Print
 - Off
 - Auto
 - ICC Profile Settings
 - RGB Source Profile
 - sRGB v3.0 (Canon)
 - Canon HDTV gamma 1.5
 - Canon HDTV gamma 1.8
 - Canon HDTV gamma 2.4
 - None
 - CMYK Sim. Profile
 - Euro Standard v1.00
 - JapanColor (Canon)
 - U.S. Web Coated v1.0
 - None
 - Grayscale Profile
 - Off
 - On

- Output Profile
 - PS Normal
 - PS Photo
 - PS TR Normal**
 - PS TR Photo
- Matching Method
 - Perceptual**
 - Saturation
 - Colorimetric
- RGB Pure Black Mode
 - Off
 - On**
- CMYK Pure Black
 - Off
 - On**
- Pure Black Text
 - Off
 - On**
- Black Overprint*
 - Off
 - On**
- Brightness
 - 85 to **100** to 115%
- Halftones
 - Error Diffusion
 - Off**
 - On
 - Resolution/Grad.
 - Text: **Resolution**, Gradation
 - Graphics: Resolution, **Gradation**
 - Image: Resolution, **Gradation**
- CMYK Overprint
 - Off**
 - On
- Advanced Smoothing
 - Advanced Smoothing
 - Off
 - Smooth 1**
 - Smooth 2
 - Graphics*
 - Off**
 - On
 - Text*
 - Off
 - On**
- Grayscale Conversion*
 - sRGB
 - NTSC**
 - Uniform RGB

- RGB Pure Black Mode
 - Off
 - On**
- CMYK Pure Black
 - Off
 - On**
- Pure Black Text
 - Off
 - On**
- Black Overprint*
 - Off
 - On**
- Brightness*
 - 85 to **100** to 115%
- Halftones
 - Error Diffusion
 - Off**
 - On
 - Resolution/Grad.
 - Text: **Resolution**, Gradation
 - Graphics: Resolution, **Gradation**
 - Image: Resolution, **Gradation**
- CMYK Overprint
 - Off**
 - On
- Advanced Smoothing
 - Advanced Smoothing
 - Off
 - Smooth 1**
 - Smooth 2
 - Graphics*
 - Off**
 - On
 - Text*
 - Off
 - On**
- Grayscale Conversion*
 - sRGB
 - NTSC**
 - Uniform RGB

- Check Counter
 - 101: Total 1*
 - (Display only)
 - 102: Total 2*
 - (Display only)
 - 108: Total (Black 1)*
 - (Display only)
 - 109: Total (Black 2)*
 - (Display only)
 - 322: Print(Full+1C/S)*
 - (Display only)

- Check Counter
 - 101: Total 1*
 - (Display only)
 - 102: Total 2*
 - (Display only)
 - 108: Total (Black 1)*
 - (Display only)
 - 109: Total (Black 2)*
 - (Display only)
 - 322: Print(Full+1C/S)*
 - (Display only)
- Configuration Page
- Network Status Print
- IPSec Policy List
- Calibration
 - Color Mismatch Corr.
 - Density Control
 - Density Median Cont.
 - Full Calibration
- PCL Utility
 - Font List
- PS Utility
 - Configuration Page
 - Font List

- Cleaning
 - A4
 - LTR
- E-Mail Print Utility
 - Received E-Mails
 - Received E-mail List
- Printing Pos. Print
- Page Count List
- Counter Report
- Serial Number
 - (Display only)
- Consumables
 - Paper Information
 - Toner Cart. Model
 - Remaining Toner

- Encrypted Print*
 - User Name
 - Job Name
 - PIN
- Secured Print*
 - User Name
 - Job Name
 - PIN
- Stored Job List*
- Stored Job Print*
 - Box No.N (N=0 to 99)
 - PIN
 - Job Name
- Job Print Log List*
- Stored Job Print Log*
- Report Print Log*
- E-Mail Print Log*

- Soft Reset (Hard Reset)
- Form Feed
- Shut Down

- Paper Source
 - Auto**
 - Drawer 1
 - Drawer 2*
 - Multi-Purpose Tray
- MP Tray Paper Size
 - A6
 - A5
 - A5R
 - B5
 - A4
 - LTR**
 - LGL
 - EXEC
 - Mixed Sizes
 - Custom Size
 - Custom Size R
 - Env. ISO-C5
 - Env. Monarch
 - Env. No.10
 - Env. DL
 - Index Card
 - STMT
 - FLSC
 - 16K
- MP Tray Priority
 - Off**
 - On

- Job Timeout
 - 0 to 3600 seconds
- Print PS Errors
 - Off**
 - On
- ICC Profile Settings
 - RGB Source Profile
 - sRGB v3.0 (Canon)**
 - Canon HDTV gamma 1.5
 - Canon HDTV gamma 1.8
 - Canon HDTV gamma 2.4
 - None
 - CMYK Sim. Profile
 - Euro Standard v1.00
 - JapanColor (Canon)
 - U.S. Web Coated v1.0
 - None**
 - Grayscale Profile
 - Off**
 - On
 - Output Profile
 - PS Normal
 - PS Photo
 - PS TR Normal**
 - PS TR Photo
 - Matching Method
 - Perceptual**
 - Saturation
 - Colorimetric

Drawer 1 Size

- A6
- A5
- A5R
- B5
- A4
- LTR**
- EXEC
- Mixed Sizes
- Custom Size
- Custom Size R
- STMT
- 16K

Drawer 2 Size*

- Mixed Sizes
- Auto**
- Custom Size
- Custom Size R
- FLSC
- 16K

Standard Paper Size

- A6
- A5
- B5
- A4
- LTR**
- LGL
- EXEC
- Env. ISO-C5
- Env. Monarch
- Env. No.10
- Env. DL
- Index Card
- STMT
- FLSC
- 16K

Diff. Paper Tray

- Off**
- On

Auto Selection

- Multi-Purpose Tray
 - Off
 - On**
- Drawer 1
 - Off
 - On**
- Drawer 2*
 - Off
 - On**

Default Paper Type

- Plain**
- Plain L
- Plain L2
- Heavy 1
- Heavy 2
- Heavy 3
- Transparency
- Envelope
- Labels
- Rough

MP Tray Paper Type

- Plain
- Plain L
- Plain L2
- Heavy 1
- Heavy 2
- Heavy 3
- Transparency
- Envelope
- Labels
- Rough
- Mixed Types**

Drawer 1 Type

- Plain
- Plain L
- Plain L2
- Heavy 1
- Heavy 2
- Rough
- Mixed Types**

Drawer 2 Type*

- Plain
- Plain L
- Plain L2
- Heavy 1
- Heavy 2
- Heavy 3
- Rough
- Mixed Types**

Manual 2-Sided (MP)

- 1st Side**
- 2nd Side

2-Sided Printing

- Off**
- On