

Menu Route Map

Network Settings

- Select Wired/Wireless LAN
 - Wired LAN, Wireless LAN
- Wireless LAN Settings
 - WPS Push Button Mode
 - WPS PIN Code Mode
 - SSID Settings
 - Select Access Point
 - Enter Manually
 - Security Settings: None, WEP (Open System, Shared key), WPA/WPA2-PSK (Auto, AES-CCMP)
 - Power Save Mode
 - Off, On
 - Wireless LAN Information
 - MAC Address
 - Wireless LAN Status
 - Latest Error Information
 - Channel
 - SSID Settings
 - Security Settings
 - Power Save Mode

TCP/IP Settings

- IPv4 Settings
 - IP Address Settings
 - Auto Acquire
 - Select Protocol: Off, DHCP, BOOTP, RARP
 - Auto IP: Off, On
 - Manually Acquire
 - IP Address: 0.0.0.0
 - Subnet Mask: 0.0.0.0
 - Gateway Address: 0.0.0.0
 - Check Settings
 - Auto Acquire
 - IP Address
 - Subnet Mask
 - Gateway Address
 - PING Command
 - DNS Settings
 - DNS Server Settings
 - Primary DNS Server: 0.0.0.0
 - Secondary DNS Server: 0.0.0.0
 - DNS Host Name/Domain Name Settings
 - Host Name
 - Domain Name
 - DNS Dynamic Update Settings
 - Off
 - On: DNS Dynamic Update Interval 0 to 24 to 48 (hr.)
 - mDNS Settings
 - Off
 - On: mDNS Name
 - DHCP Option Settings
 - Acquire Host Name: Off, On
 - DNS Dynamic Update: Off, On
- IPv6 Settings
 - Use IPv6
 - Off, On, Check Settings
 - Stateless Address Settings
 - Off, On, Check Settings
 - Use DHCPv6
 - Off, On, Check Settings
 - DNS Settings
 - DNS Host Name/Domain Name Settings
 - Use IPv4 Host/Domain
 - Off (Host Name, Domain Name), On
 - DNS Dynamic Update Settings
 - Off
 - On
 - mDNS Settings
 - Off
 - On
 - Register Manual Address: Off, On
 - Register Stateful Address: Off, On
 - Register Stateless Address: Off, On
 - DNS Dynamic Update Interval 0 to 24 to 48 (h.)

- WINS Settings
- WINS Resolution
 - Off
 - On (WINS Server Address: 0,0,0,0)
- Scope ID
- LPD Print Settings
- Off, On
- RAW Print Settings
- Off, On
- WSD Settings
- WSD Print Settings
 - Use WSD Print: Off, On
 - Use WSD Browsing: Off, On
- WSD Scan Settings
 - Use WSD Scan: Off, On
 - Use Computer Scan: Off, On
 - Use Multicast Discovery: Off, On
- Use HTTP
- Off, On
- Port Number Settings
- LPD: 1 to 515 to 65535
- RAW: 1 to 9100 to 65535
- HTTP: 1 to 80 to 65535
- POP3 Receiving: 1 to 110 to 65535
- SMTP Sending: 1 to 25 to 65535
- SNMP: 1 to 161 to 65535
- WSD Search: 1 to 3702 to 65535
- Multicast Discovery: 1 to 427 to 65535
- MTU Size
- 1300, 1400, 1500

SNMP Settings

- SNMPv1 Settings
 - Off, On
- SNMPv3 Settings
 - Off, On
- Acquire Printer Management Information from Host
 - Off, On

Dedicated Port Settings

- Off, On

Waiting Time for Connection at Startup

- 0 to 300 (sec.)

Ethernet Driver Settings

- Auto Detect
 - Off
 - Communication Mode: Half Duplex, Full Duplex
 - Ethernet Type: 10BASE-T, 100BASE-TX
 - On
- Mac Address

IEEE 802.1X Settings

- Off, On

Initialize Network Settings

Preferences

Sound Volume Control

- Fax Tone
 - Off
 - On
 - Fax Volume: 1 to 3
- Ring Tone
 - Off
 - On
 - Ring Tone Volume: 1 to 3
- TX Done Tone
 - Off
 - On
 - TX Done Volume: 1 to 3
 - Only When Error Occurs
 - TX Done Volume: 1 to 3
- RX Done Tone
 - Off
 - On
 - RX Done Volume: 1 to 3
 - Only When Error Occurs
 - RX Done Volume: 1 to 3
- Scanning Done Tone
 - Off
 - On
 - Scanning Done Volume: 1 to 3
 - Only When Error Occurs
 - Scanning Done Volume: 1 to 3
- Entry Tone
 - Off
 - On
- Invalid Entry Tone
 - Off
 - On
- Restock Supplies Tone
 - Off
 - On
- Warning Tone
 - Off
 - On
- Job Done Tone
 - Off
 - On
- Energy Saver Alert
 - Off
 - On

Display Settings

- Default Screen after Startup/Restoration
 - Copy, Fax, Scan, Memory Media Print
- Brightness
 - 4 to 0
- Invert Screen Colors
 - Off, On
- Millimeter/Inch Entry Switch
 - Millimeter, Inch
- Gram/Pound Switch
 - Gram, Pound
- Message Display Time
 - 1 to 2 to 5 (sec.)
- Scrolling Speed
 - Slow, Standard, Fast
- Cursor Movement
 - Auto, Manual
- Language
 - English, French, Spanish, Portuguese
- Remote UI Language
 - English, French, Spanish, Portuguese

Timer Settings

Date/Time Settings

- Date Format
 - YYYY MM/DD, MM/DD/YYYY, DD/MM/YYYY
- Time Format
 - 12 Hour (AM/PM), 24 Hour
- Current Date/Time Settings
- Time Zone
 - UTC-12:00 to UTC-5:00 to UTC+12:00
- Daylight Saving Time Settings
 - Off
 - On
 - Start (M/W/D), End (M/W/D)

Auto Reset Time

- 0 (Auto Reset is disabled), 1 to 2 to 9 (min.)

Function After Auto Reset

- Default Function, Selected Function

Auto Sleep Time

- 20 to 240 (min.)

Auto Offline Time

- 0 (The machine remains online), 1 to 5 to 60 (min.)

Common Settings

Drawer Auto Selection On/Off

- Copy
 - Multi-Purpose Tray
 - Off, On
 - Drawer 1
 - Off, On
- Printer
 - Drawer 1
 - Off, On
- Fax
 - Multi-Purpose Tray
 - Off, On
 - Drawer 1
 - Off, On
- Other
 - Multi-Purpose Tray
 - Off, On
 - Drawer 1
 - Off, On

Copy Settings

Change Default Settings

- Number of Copies
 - 1 to 99
- Density
 - 4 to ±0 to +4
- Original Type
 - Text/Photo/Map (Speed), Text/Photo/Map, Text/Photo/Map (Quality), Printed Image, Text
- Copy Ratio
 - Custom Ratio, 100% (Direct), 400% (MAX), 200%, 129% STMT->LTR, 78% LGL->LTR, 64% (LTR->STMT), 50%, 25%(Min)
- Paper
 - Multi-purpose tray, Drawer 1
- N on 1
 - Off, 2 on 1, 4 on 1, ID Card Copy
- Collate
 - Off, On
- Erase Frame
 - Off, On
- Sharpness
 - 3 to ±0 to +3
- Color Balance
 - Yellow: -8 to ±0 to +8, Magenta: -8 to ±0 to +8, Cyan: -8 to ±0 to +8, Black: -8 to ±0 to +8

Fax Settings

Basic Settings

- Register Unit Telephone Number
- Select Line Type
 - Pulse, Tone
- Off-Hook Alarm
 - Off
 - On
 - Off-Hook Alarm Volume: 1 to 3

TX Function Settings

- Change Default Settings
 - Resolution
 - 200 x 100 dpi (Normal), 200 x 200 dpi (Fine), 200 x 200 dpi (Photo), 200 x 400 dpi (Superfine), 400 x 400 dpi (Ultrafine)
 - Density
 - 4 to ±0 to +4
 - Sharpness
 - 3 to ±0 to +3
- Register Unit Name (Fax)
- ECM TX
 - Off, On
- Set Pause Time
 - 1 to 2 to 15 (sec.)
- Auto Redial
 - Off
 - On
 - Redial Times: 1 to 2 to 10 (times)
 - Redial Interval: 2 to 99 (min.)
 - Redial When Error Occurs: Off, On
- TX Terminal ID
 - Off
 - On
 - Print Position: Inside Image Area, Outside Image Area
 - Mark Number as: FAX, TEL
- Check Dial Tone Before Sending
 - Off, On

RX Function Settings

- ECM RX
 - Off, On
- Incoming Ring
 - Off
 - On
 - Ring Times: 1 to 2 to 99 (times)
- Remote RX
 - Off
 - On
 - Remote RX ID: 00 to 25 to 99
- Switch to Auto RX
 - Off
 - On
 - Ring Time Until Auto RX: 1 to 15 to 99 (sec.)

RX Print Settings

- Reduce RX Size
 - Off
 - On
 - Reduction Ratio: Auto, 97, 95, 90, 75 (%)
 - Reduction Direction: Vertical/Horizontal, Vertical Only
- RX Page Footer
 - Off, On
- Continue Printing When Toner Is Low
 - Off, On

Fax Setup Guide

Scan Settings

USB Memory Settings

- Change Default Settings
 - Scan Size
 - LTR, LGL, STMT
 - File format
 - PDF (Compact), PDF, JPEG, TIFF
 - Density
 - 4 to ±0 to +4
 - Original Orientation
 - Portrait, Landscape
 - Original Type
 - Text, Text/Photo, Photo
 - Sharpness
 - 3 to ±0 to +3
 - DATA SIZE
 - Small: Memory Priority, Standard, Large: Image Quality Priority

Output File Image Settings

- YCbCr TX Gamma Value
 - Gamma 1.0, Gamma 1.4, Gamma 1.8, Gamma 2.2
- PDF (Compact) Image Qlty. Level
 - Image Level in Text/Photo Mode or Photo Mode
 - Data Size Priority, Normal, Image Quality Priority
 - Image Level in Text Mode
 - Data Size Priority, Normal, Image Quality Priority

Shortcut Key Settings

- Register
 - Scan -> PC1
 - Off
 - On
 - USB Connection
 - Color Scan, B&W Scan, Custom 1, Custom 2
 - Network Connection
 - Color Scan, B&W Scan, Custom 1, Custom 2
 - Scan -> PC2
 - Off
 - On
 - USB Connection
 - Color Scan, B&W Scan, Custom 1, Custom 2
 - Network Connection
 - Color Scan, B&W Scan, Custom 1, Custom 2
- Confirm Destination
 - Scan -> PC1
 - Scan -> PC2

Memory Media Print Settings

Change Default Settings

- Number of Copies
 - 1 to 99
- Paper
 - Multi-Purpose Tray, Drawer 1
- N on 1
 - Off, 2 on 1, 4 on 1
- Print Date
 - Off, On
- Print File Name
 - Off, On
- Original Type
 - Photo Priority, Text Priority
- Brightness
 - 2 to ±0 to +2
- Halftones
 - Gradation, Error Diffusion

Default Display Settings

- Details
- Images

File Sort Default Settings

- Name (Ascending)
- Name (Descending)
- Date/Time (Ascending)
- Date/Time (Descending)

File Name Display Format

- Short File Name
- Long File Name

Printer Settings

Paper Size Override

- Off, On

Menu Route Map

